

### BEERMATIC DUAL TAP

## **DBF-AS65WE-EU-HC Automatic Draft Beer Dispenser** with Foaming Mechanism

MODELS AVAILABLE

☑ DBF-AS65WE-EU-HD Twin system















The draft beer dispenser is compatible with glasses of 50 mm or over in inside diameter and 105 mm or less in outside diameter. There must be a difference of 20 mm or over in height between a large size glass and a medium size glass. If you use glasses or tumblers of other sizes, please consult our installation manual.

SERIES: Automated draft beer dispenser

ITEM: B078-C101



#### **FEATURES:**

High-performance, flash chiller in compact design, counter-top: draft beer can be served from ambient temperature kegs.

Hands-free portion control allows set quantity of chilled draft beer and beer head to be served by the push of a button. Beer is dispensed first, followed by beer head, which is poured from a separate spout. Thus, portion control can be very accurate, without spillage of beer and/or beer head. Designed for high-volume outlets: after initial freeze down 65 ltr. of beer can be served consecutively in 4 hr (Glasses @ 453 ml, Air temp. @ 24° C, Beer temp @ 18°C, dispensing rate 4 glasses per minute). Recovery time: 45 minutes. Quantity available after recovery time: 10.2 ltr.

#### Easy to operate, set, and clean:

- Manually raising or lowering the glass/glass support base to the desired distance from each spout makes the system compatible with glasses of various sizes.
- Folding or unfolding the spring-loaded base, beer can be served from each single tap into two memorized sizes.
- Two different types of beer can be served at one time: the system is equipped with two separate circuits.
- Manual pouring can be quickly implemented by simply raising the control panel. Beer is poured by pulling the tap forward, beer head by pushing it backwards.

#### The Hoshizaki Beermatic Dual Tap is great for:

- Quality servings the perfect serve is achieved without efforts even from inexperienced staff. Quantity of beer head is adjustable according to best preference and local taste.
- Speed of service the unit stops dispensing at the right level, precisely and timely, without the need for top-ups.
- Labour saving the Owner/Operator can efficiently work on other tasks while beer is dispensed. No more cleaning time, as spillage is no longer a problem.
- Cost control spillage is curbed to virtually 0%; a portion counter monitors the number of portions served.



#### **EXTERIOR FINISH**

Drive cover: ABS plastic Cabinet: Painted steel

Refrigerant: R600a (80 g)

#### **OPERATING CONDITIONS LIMITATIONS**

- Ambient Temperature Range: 5°C / 32°C
- Voltage Range: Rated voltage ± 6%

MODEL	Refrigeration System	Instant Output		Flow Rate. Recovery Time.	Electrical Connection	Electrical Consumption (power factor 78%)	Amperage Rating	Electrical Circuit Breaker Protection
		after initial freeze down	after 45′ recovery time					
DBF-AS65WE- EU-HC	Air cooled	65 ltr.	76 ltr.	4 glasses/ 60" @ 453 ml 10.2 lt every 45'	220-240v/50Hz	245 W	Running: 1.3A Rated Motor: 1.3A Starting: 6A	10 A

TECHNICAL CERTIFICATIONS










For more information visit our website at www.hoshizaki-europe.com Hoshizaki UK retains the right to change products and their specifications without prior notice.

## **BEERMATIC DUAL TAP**



# DBF-AS65WE-EU-HC Automatic Draft Beer Dispenser with Foaming Mechanism



#### SHIPPING SPECIFICATIONS

MODEL	NODEL Net Equipment Dimensions			Crated Dimensions			
	W x D x H (mm)	Net Weight (kg)	W x D x H (mm)	Gross Weight (kg)	Volume (m³)		
DBF-AS65WE-EU-HC	367 x 674 x 764	50	466 x 795 x 858	57	0.318		

#### ACCESSORIES

Instruction Manual, Platform Assembling Instructions, Instruction Label, Instruction Sheet, Hook, Cylinder Chain, Cleaning Sponge x 6, Cleaning Brush (Large x 1, Small x 1), Spanner, Nozzle Cap x 8, 0-ring (L) P21, Hook Mounting Screw x 2, Platform x 2, Drain pan x 2, Grille x 2.



Hoshizaki Belgium: Hoshizaki Denmark: Hoshizaki Deutschland: Hoshizaki France: Hoshizaki Iberia: Hoshizaki Italia: info@hoshizaki.be info@hoshizaki.dk vertrieb@hoshizaki.de info@hoshizaki.fr info@hoshizaki.es info@hoshizaki.it

Hoshizaki Middle East: Hoshizaki Netherlands: Hoshizaki Norge: Hoshizaki United Kingdom: Hoshizaki Sverige: Export Countries: sales@hoshizaki.ae info@hoshizaki.nl salg@hoshizaki.no uksales@hoshizaki.uk orderSE@hoshizaki.dk sales@hoshizaki.nl