

# STAR ICE MAKER, SELF CONTAINED IM-65NE-HC-S

Product series: IM

Item number: M066-D008



This Hoshizaki IM-65NE-HC-S is a self-contained special ice maker producing up to 20 kg of high-quality Star Ice per 24 hours.

Expand your creative horizon and your craft's aesthetic possibilities with the help of our special ice makers that produce different, extraordinary shapes of ice - Specially tailored for cocktail bars that like to differentiate themselves from others, whilst never compromising on the taste and quality of their drinks. With perfect ice characteristics still in focus, you can now add a decorative highlight to your cocktails and long drinks.

All special ice makers are equipped with an electronic control system. This ensures an optimized ice-making process, even under varying circumstances. Without additional manual assistance or adjustments required, our Special Ice Makers produce generous amounts of ice cubes, at a consistently high quality.

#### Sustainable

The IM-65NE-HC-S uses refrigerant R290.

This natural refrigerant is not only climate-friendly but also boosts the machine, when it comes to performance and production capacity.

#### Material

The exterior is made of stainless steel. The closed water circuit provides maximum protection against any type of contamination during the entire cubing process. All Hoshizaki machines are easy to use, clean, and maintain.

#### Unique Technology

A dedicated jet of fresh water is injected into each of the closed cells. Excess water leaves the closed cell through a set of outlets. The cell walls block the freezing water's expansion from all sides while reaching down to  $-30^{\circ}\text{C}$  during the cubing process. Thanks to the automatic rinse cycles, impurities such as minerals, are eliminated from the water resulting in the purest ice possible while your machine is protected from calcification and mineral build-up.

#### Smart Design

Like all Hoshizaki Ice makers, the IM-65NE-HC-S is designed to last and comes with smart design extras such as a magnetic water pump without direct coupling. This element prevents leakage from the water circuit and improves the life expectancy of the machine.

#### Perfect Fit

With outside dimensions W x D x H of 633 x 506 x 840 mm, the IM-65NE-HC-S is compact and is a perfect fit for small spaces.

#### Plug&Play

The smart plug-and-play design guarantees an easy and quick set-up.

## SPECIFICATIONS

<b>Product title</b>	Star Ice Maker, Self Contained
<b>Production capacity (kg/24h) approx.</b>	20
<b>Storage bin capacity (kg) approx.</b>	26
<b>Electric connection</b>	1/220 - 240V/50Hz
<b>Electric consumption (kW)</b>	0.32
<b>Outside dimensions W x D x H (mm)</b>	633 x 506 x 840
<b>Ice type</b>	Star

<b>Refrigerant</b>	R290
<b>CO2 equivalent (kg)</b>	315
<b>Cooling system</b>	Air Cooled
<b>Product configuration</b>	Self Contained
<b>Net weight (kg)</b>	51
<b>Gross weight packed (kg)</b>	61